


Models with touchscreen

## SiriusXM® Radio\*

Available on a subscription basis only. For more information or to subscribe, contact your dealer, or visit [www.siriusxm.com](http://www.siriusxm.com).



**Source:** Select the XM icon.

**Open/close:** Display or hide the channel list or preset list.

**Scan:** Scan for each station with a strong signal.

**Category:** Change the category.

**Presets:** Select and hold a preset number to store the current station. Select a preset number to select a previously stored station.

**Skip:** Change the selection. Press and hold to skip rapidly.

**Channel:** Change the channel. Press and hold to skip 10 channels at a time.



To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual at [owners.honda.com](http://owners.honda.com).

Available in the U.S. and Canada, except Hawaii, Alaska, and Puerto Rico.  
XM® is a registered trademark of SiriusXM Radio, Inc.  
\*if equipped