

### Climate Control System

The automatic climate control system maintains the interior temperature you select. The system also selects the proper mix of heated or cooled air that raises or lowers the interior temperature to your preference as quickly as possible.

- **Front Operation - Climate Control System**

Models with Display Audio  
Models without SYNC button

**A/C** (Air Conditioning) Icon


**MODE** Control Icon  
(Dashboard vents)

**MODE** Control Icon  
(Floor vents)

Fan Control Icon

**MODE** Control Icon  
(Floor and defroster vents)

**MODE** Control Icon  
(Dashboard and floor vents)



**CLIMATE** Button

Temperature Control Dial


Fan Control Dial

**AUTO** Button

**ON/OFF** (On/Off) Button

(Recirculation) Button

(Fresh Air) Button



# VEHICLE CONTROLS

Models with Display Audio

Models with SYNC button

**A/C** (Air Conditioning) Icon

**MODE** Control Icon  
(Dashboard vents)

**MODE** Control Icon  
(Floor vents)


Fan Control Icon

Fan Control Buttons

Driver's Side  
Temperature  
Control Dial

**AUTO** Button


**ON/OFF** (On/Off) Button



**MODE** Control Icon  
(Floor and  
defroster vents)

**MODE** Control Icon  
(Dashboard and  
floor vents)

**CLIMATE** (CLIMATE)  
Button



Passenger's  
Side  
Temperature  
Control Dial

**SYNC** (Synchronization) Button

**ON/OFF** (On/Off) Button



(Recirculation) Button