

SMS Text Messaging and E-Mail*1

HFL can display newly received text messages as well as the last 20 messages received on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase. To use the text message function, it may be necessary to set up on your phone.

1. A pop-up appears and notifies you of a new text or e-mail message.
2. Select Read to listen to the message.
The text or e-mail message is displayed.
The system automatically starts reading out the message
3. To discontinue the message read-out, select Stop.



**1 - If equipped*