

AUDIO AND CONNECTIVITY

Learn how to operate the vehicle's audio system.

Basic Audio Operation

Connect audio devices and operate buttons and displays for the audio system.

■ USB Port


Install the iPod[®] USB connector or the USB flash drive to the front USB port.

Models with Display Audio

The USB port (1.5A) is for charging devices, playing audio files and connecting compatible phones with Apple CarPlay[™] or Android Auto[™]

In the console compartment*1

The USB port (1.0A) is for playing audio files on the USB flash drive and connecting a cellular phone and charging device.




**1 - If equipped*

Tip: To prevent any potential issues, be sure to use an Apple MFi Certified Lightning Connector for Apple CarPlay™ or a USB cable certified by USB-IF to be compliant with USB 2.0 Standard for Android Auto™.

■ Accessory Power Socket

There is an accessory power socket in the front console panel. It can be used when the vehicle is ON or in ACCESSORY Mode.

Open the cover to use it.




NOTICE

Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

■ Audio Remote Controls

You can operate certain functions of the audio system using the steering wheel controls.



Volume Bar (+/-): Press the +/- at the ends of the bar to adjust the volume.


Up/Down Arrows: Press to cycle through the available audio modes.

■ Adjusting the Sound

Models with Display Audio

1. Press the Sound button.
2. Select Menu
3. Select Sound.

Select a tab from the following choices:




- BAS-MID-TRE: Bass, Middle, Treble
- FAD-BAL-SUBW^{*1}: Fader, Balance, Subwoofer^{*1}
- SVC-Neural^{*1}: Speed Volume Compensation, DTS Neural Surround™^{*1}

**1 - If equipped*

Display Audio System

Use simple gestures—including touching, swiping and scrolling—to operate certain audio functions.



Note: Some items may be grayed out during driving to reduce the potential for distraction. You can select them when the vehicle is stopped or use voice commands.

Wearing gloves may limit or prevent touchscreen response.

Wi-Fi Connection*1


FM/AM Radio

Play FM or AM radio stations.

Auto when conditions allow you to do so safely. See your Owner's Manual at owners.honda.com (U.S.) or myhonda.ca (Canada) for further license and warranty terms.

**1 - If equipped*

Models with Display Audio




*1:Some or all of the lists may not be displayed.

SiriusXM[®]*1

Models with Display Audio

Available on a subscription basis only. For more information or to subscribe, contact your dealer, or visit www.sirius.com/subscribenow (U.S.) or www.sirius.ca/subscribe-now (Canada).



*1:Some or all of the lists may not be displayed.

* Not available on all models


**1 - If equipped*

To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual at owners.honda.com (U.S.) or myhonda.ca (Canada).

iPod®

Play and operate an iPod®*14 through the vehicle's audio system. Connect your device to the USB port (see USB Port).

Models with Display Audio



*1. Some or all of the lists may not be displayed.


*14 - iPod and iPhone are trademarks of Apple, Inc.

■ Searching for Music

Models with Display Audio

Use the touchscreen to search for tracks stored on the iPod.

1. Select Menu, then select Music Search.
2. Select the items on that menu.




Pandora®*13

Your audio system allows you to listen to music from the Pandora® app on a compatible smartphone. This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® system, or with an iPhone®, you can connect using your USB cable to the USB port.

**13 - US models only, if equipped*

AUDIO AND CONNECTIVITY




* Not available on all models

USB Flash Drive

Your audio system reads and plays sound files on a USB flash drive in either MP3, WMA, or format. Connect your USB flash drive to the USB port .

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle. Launch streaming audio on your phone only when it is safe to do so.

Models with Display Audio



*1: Only AAC format files recorded with iTunes are playable on this unit.

*2: Some or all of the lists may not be displayed.

■ Searching for Music

Models with Display Audio

Use the touchscreen to search for tracks.

1. Select MENU and select Music Search.
2. Select Music .
3. Select a folder.
4. Select a track.




Bluetooth[®] Audio

Play streaming or stored audio from your compatible phone when it is paired to *Bluetooth*[®] HandsFreeLink[®] (see Pairing a Phone). Visit *handsfreelink.com* (US) to check phone compatibility. Canada customers can phone (855)-490-7351 for any HandsFreeLink[®] related inquiry. Standard data rates apply with your phone service provider.

AUDIO AND CONNECTIVITY

Models with Display Audio



*1: Depending on the *Bluetooth*[®] device you connect, some or all of the lists may not be displayed.

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle. Launch streaming audio on your phone only when safe to do so.