

Climate Control System

The automatic climate control system maintains the interior temperature you select. The system also selects the proper mix of heated or cooled air that raises or lowers the interior temperature to your preference as quickly as possible.

- **Front Operation - Climate Control System**

VEHICLE CONTROLS

Models with Display Audio without SYNC button

A/C (Air Conditioning) Icon

MODE Control Icon
(Dashboard vents)

MODE Control Icon
(Floor vents)

Fan Control Icon

MODE Control Icon
(Floor and defroster vents)

MODE Control Icon
(Dashboard and floor vents)




Temperature Control Dial

AUTO Button



(Recirculation) Button

CLIMATE Button



Fan Control Dial

ON/OFF Button



(ON/OFF) Button

(Fresh Air) Button

Models with Display Audio with SYNC button

A/C (Air Conditioning) Icon

MODE Control Icon
(Dashboard vents)

MODE Control Icon
(Floor vents)

Fan Control Icon

 (Fan Control) Buttons

Driver's Side Temperature Control Dial

AUTO Button

 (ON/OFF) Button




MODE Control Icon
(Floor and defroster vents)

MODE Control Icon
(Dashboard and floor vents)

CLIMATE Button

Passenger's Side Temperature Control Dial

SYNC (Synchronization) Button

 (Recirculation) Button

