


Information Display*1 / Multi-Information Display*1

Consists of several displays that provide you with useful information.

Models with Information Display


To switch the display press the select/reset knob.



Models with Multi-Information Display*1

Main Displays

To switch the display press the information button.



* Not available on all models

Lower Displays

Press the Select/Reset button to cycle through the lower displays shown below:

INSTRUMENT PANEL

