

## ■ Reverse Tilt Door Mirrors\*1

To activate this feature, set the power mode to ON and slide the selector switch to the left or right side. If activated, either side door mirror can tilt downward when you shift to Reverse (R) to improve visibility on the selected side of the vehicle when reversing. The mirror returns to its original position when you shift out of Reverse.

To enable reverse tilt, use the Vehicle Settings feature (See Customized Features)



*\*1 - If equipped*