

### **Customized Features**

When you customize settings, make sure that the vehicle is at a complete stop and shift to Park (P).

# VEHICLE CONTROLS

---

## Models with Display Audio



### ■ To Change a Setting

#### Models with Display Audio

1. Press the **Home** button.
2. Select **Settings**.
3. Select a category.
4. Select a setting option, and make your preferred changes.
5. Press the Back button to exit the menus.

## Setting the Clock

On vehicles with navigation, the time is automatically set using GPS signals. On vehicles without navigation, use the following steps to adjust the time in the clock display.

### Models with Display Audio

The vehicle is equipped with an Automatic Date & Time feature. If you would like to turn this feature off and manually adjust the time, use the following steps. Using the **Settings** menu on the audio/information screen.

1. Press the **HOME** icon, then select **Settings**.
2. Select **System**.
3. Select **Date & Time**.
4. Select **Set Date & Time**.
5. Select **Automatic Date & Time**, then select **OFF**.
6. Select **Set Time**.
7. Use the **Up** or **Down** arrow to change the time.
8. Select **Save** to set the time.

