


Homelink® Universal Transceiver*1

Program your vehicle to operate up to three remote-controlled devices around your home (such as garage doors, lighting, or home security systems) using the buttons on the bottom of the rearview mirror.



**1 - If equipped*

■ Training a Button

Park near the system you want to program, and follow the instructions.

1. Position the remote transmitter you wish to link 1 to 3 inches (3 - 8 cm) from the HomeLink® button you want to program.

2. Press and hold the desired HomeLink button. Is the HomeLink indicator (LED) **slowly flashing orange**?

YES

- 3a. Hold the button on the remote transmitter. Does HomeLink indicator (LED) change from **slowly flashing orange to rapidly flashing green or continuously on green**? The process should take less than 60 seconds.

4. Press and hold the programmed HomeLink button for about a second. Does the device (garage door opener) work?

YES

Training Complete

NO

5. Press and hold the HomeLink button again.

HomeLink LED is **continuously on green**

6. Press and hold the HomeLink button again. The remote-controlled device should operate.

Training Complete

NO

- 3b. Canadian Garage Door Opener
A. Press and release the HomeLink button. Press, hold and release the button on the remote every 2 secs. Does the HomeLink indicator (LED) change from **slowly flashing orange to rapidly flashing or continuously on green**? The process should take less than 60 seconds.

HomeLink indicator **rapidly flashes green**.

- 5a. The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g. garage door opener).

- 5b. Within 30 secs, press and hold the programmed HomeLink button for 2 secs.

To retrain a button or erase codes, see the Owner's Manual at owners.honda.com (U.S.) or honda.ca (Canada). If you need help, call HomeLink at (800) 355-3515 or visit www.homelink.com.