


Remote Engine Start with Vehicle Feedback*1

Start your vehicle's engine using the smart entry remote before you enter the vehicle.

■ Starting the Engine


Press the Lock button, then press and hold the Engine button to remotely start the engine.



When started remotely, the engine automatically shuts off after 10 minutes of idling and/or the brake pedal and ENGINE START/STOP button have not been pressed simultaneously.

**1 - If equipped*

■ Stopping the Engine



WARNING

Carbon monoxide gas is toxic and can rapidly accumulate in closed or even partly enclosed areas.

Breathing it can cause unconsciousness and even kill you.

Never use the remote engine starter with the vehicle parked in a garage or other areas with limited ventilation.