

## Playing SiriusXM® Radio

The diagram illustrates the audio system's interface for playing SiriusXM radio. It features two main screens: a top 'Driver Information Interface' and a bottom 'Audio/Information Screen'. The top screen shows a speedometer at 45 mph, a radio channel 'CH 001 Channel AAA', and a range of 320 miles. The bottom screen shows 'Album Art' for 'Genre AAA Channel AAA', a time of 12:34, and various navigation options like 'Scan', 'Category', 'Channel', and 'Skip'. A vertical sidebar on the left contains icons for AUDIO, HOME, VOL, MENU, and BACK. Arrows point from these icons and text descriptions to the corresponding elements on the screens.

**Channel Icons**  
 Select or to the previous or next channel.  
 Select and hold to rapidly skip 10 channels at a time.

**Driver Information Interface**

**Audio/Information Screen**

**AUDIO (Power/Audio) Icon**  
 Press to turn the audio system on and off.

**VOL (Volume) Icons**  
 Select to adjust the volume.

**(Menu) Icon**  
 Select to display the menu items.

**(Back) Icon**  
 Select to go back to the previous display.

**Scan Icon**  
 Select to scan each channel.

**Category Icons**  
 Select or to display and select a SiriusXM® Radio category.

**Station Art**

**Open/Close Icon<sup>\*1</sup>**  
 Displays/hides the detailed information.

**Preset Icons**  
 Tune the preset radio station. Select and hold the preset icon to store that station. Select to display preset 7 onwards.

**Skip Icons**  
 Select or to change section in the channel. Select and hold to move rapidly within the section.

\*1: Some or all of the lists may not be displayed.