

AUDIO AND CONNECTIVITY

How to operate the vehicle's audio system.

Basic Audio Operation

Connect audio devices and operate buttons and displays for the audio system.


Note: When the screen is viewed through polarized sunglasses, a rainbow pattern may appear on the screen due to optical characteristics of the screen.

■ USB Port

Install the iPod® USB connector or the USB flash drive to the USB port.

Models with Color Audio

The USB port (1.0A) is for playing audio files on a USB flash drive, connecting a cellular phone and charging devices.



Models with Display Audio

The USB ports (2.5A) are for charging devices, playing audio files and connecting compatible phones with Apple CarPlay® or Android Auto™.

Tip: To prevent any potential issues, be sure to use an Apple MFi Certified Lightning Connector for Apple CarPlay® or a USB cable certified by USB-IF to be compliant with USB 2.0 Standard for Android Auto™.

■ Accessory Power Socket

The accessory power socket can be used when the power mode is in ACCESSORY or ON.

Console panel

Open the cover to use it.



NOTICE


Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

■ Adjusting the Sound

Models with Color Audio

Press the sound button and rotate the selector knob to scroll through the following choices.

- Bass
- Middle
- Treble
- Fader
- Balance
- Speed-sensitive Volume Compensation



Rotate the selector knob to adjust the sound setting, then press the selector knob.


Models with Display Audio

Touch items on the screen to make and enter selections.

1. Press the Home button.
2. Select an audio source icon.
3. Select Sound.
4. Select the setting you want.
5. Select Save.

Select an item from the following choices:


- **Bass / Treble:** Treble, Midrange, Bass



- **Balance / Fader:** Balance, Fader
- **DTS Neural Surround*1:** DTS Neural Surround™
- **Speed Volume Compensation:** Speed Volume Compensation (SVC)

■ Audio Remote Controls


Models with Color Audio



Volume Buttons (+/-): Press to adjust the volume.

SOURCE Button: Press to cycle through the available audio modes.

Models with Display Audio




Volume Buttons (+/-): Press to adjust the volume.

Left Selector Wheel: Roll up/down to cycle through the available audio modes.

Color Audio System

Use the buttons to control the color audio system.



1. Day/Night Button
2. Radio Button
3. Media Button
4. Volume/Power Knob
5. Seek/Skip Button
6. Seek/Skip Button
7. Audio Information Screen
8. Phone Button
9. Sound Button
10. Selector Knob
11. Menu/Clock Button
12. Back Button
13. Preset Buttons (1-6)

Display Audio System

Use simple gestures—including touching, swiping and scrolling—to operate certain audio functions.



1. **Audio/Information Screen**

2. **Home Button**

3. **Back Button**

4. **Day/Night Button**

5. **Seek/Skip Button**

6. **Volume Power**

Note: Some items may be grayed out during driving to reduce the potential for distraction. You can select them when the vehicle is stopped or use voice commands.

Wearing gloves may limit or prevent touchscreen response.