

■ Rear Entertainment System Accessibility

The Blu-ray/DVD Rear Entertainment System (RES) supports an accessibility function which allows the user to enable audio feedback of on-screen operations through the wireless and wired headphones.

Selecting the Accessibility Function

1. Press the Power button on the remote (from the rear seat).
2. Select Accessibility and then press the Enter button on the remote.

The following items are available:

- **Enable Accessibility:** Turns the accessibility mode on or off.
- **Speed of Audio Output:** Adjusts to increase or decrease the speed of audio output.
- **Enable 3 Key Push:** Turns the 3-button push behavior on or off.

To change function status:

Press any of the following colored buttons on the RES remote three times to turn a function on or off, or to change a function setting.

Red button: Accessibility



Green button: Subtitles

Yellow button: Secondary Audio

Blue button: Audio Format Switching

Note: Since the accessibility function is set to OFF by default, you must set it to ON before using it.

To change the position of the Video Accessibility icon, press and hold the ENTER button on the RES then drag the icon to the desired location.



NOTICE

This vehicle's overhead mounted display includes mercury-containing components. Upon removal or replacement, please reuse, recycle, or dispose of as hazardous waste.

⚠ CAUTION

Radio Frequency Radiation Exposure. The Rear Entertainment System remote complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC Radio Frequency (RF) Exposure Guidelines. The Rear Entertainment System remote should be kept at least 7.9 inches (20 cm) or more away from a person's body when operated.