


System Updates



■ Wireless Connection Setup

1. Press the Home button.
2. Select System Updates.
3. Select Settings.
4. Select Connection Setup.
5. Select Change Mode.
6. Select Network, then Save.
The display returns to the network list.
7. Select an access point from the network list, then Save.
If the audio system requires a password, enter a password.



■ Wireless Updating

1. Select Home.
2. Select System Updates.
3. Select via Wireless.
4. Select Download Now.
A notification appears on the screen.
5. Select Install Now or Install while Vehicle OFF.
A notification appears on the screen if the update is successful.



■ USB Updating

Download the update

AUDIO AND CONNECTIVITY

1. Select Home.
2. Select System Updates.
3. Select via USB.
A notification appears on the screen.

4. Connect a USB device into the front USB port.
The inventory data is copied into the USB device.

5. Remove the USB device from the USB port.
6. Connect the USB device into your computer, and then download the update files.

Follow the link to download the required software update files. Refer to *<https://usb.honda.com>* for instructions.

