

Playing SiriusXM® Radio *

The diagram shows a multi-tiered display interface. At the top is a 'Multi-Information Display' showing '002345 miles', a 'D' gear indicator, and '63°F'. Below it is the 'Audio/Information Screen' displaying 'Album Art', 'MAP', 'SOURCE', 'CH 000 AAA', '12:34', and 'Live'. At the bottom is a 'Station Art' section with 'Scan', 'Category', 'Channel', and 'Skip' options. A vertical sidebar on the left contains icons for AUDIO, HOME, VOL, MENU, BACK, and a multi-line icon. A bottom row contains 'Preset Icons' (1-7) and a '>>' icon.

Power/AUDIO (Power/Audio) Icon
Select to turn the audio system on and off.

VOL (Volume) Icons
Select to adjust the volume.

MENU (Menu) Icon
Select to display the menu items.

BACK (Back) Icon
Select to go back to the previous display.

Scan Icon
Select to scan each channel.

Category Icons
Select **◀** or **▶** to display and select a SiriusXM® Radio category.

Multi-Information Display

Channel Icons
Select **◀◀** or **▶▶** to the previous or next channel.
Select and hold to rapidly skip 10 channels at a time.

Audio/Information Screen

Station Art

Open/Close Icon^{*1}
Displays/hides the detailed information.

Skip Icons
Select **◀◀** or **▶▶** to change section in the channel.
Select and hold to move rapidly within the section.

Preset Icons
Tune the radio frequency for preset memory.
Select and hold the preset icon to store that station. Select **>>** to display preset 7 onwards.

*1: Some or all of the lists may not be displayed.

* Not available on all models