

Eco Assist® System

Ambient Meter

With SPORT mode off, the color of the ambient meter changes to green to indicate that the vehicle is being driven in a fuel efficient manner.



The message is displayed for a few seconds when the ECON button is pressed.

ECON Mode Indicator

Comes on when the ECON button is pressed.



ECON Button

Helps maximize fuel economy.



Drive Cycle Score/Lifetime Points

- Comes on when the power mode is in VEHICLE OFF.



Eco Drive Display

- Keep the vehicle icon near the center of the circle.

Fuel economy is: Worse



Aggressive Deceleration

Better



Moderate Deceleration

Best



Slow Acceleration/
Deceleration

Better



Moderate Acceleration

Worse



Aggressive Acceleration