
# ■ To Switch ACC with Low Speed Follow to Cruise Control



Press and hold the (a) (interval) button for one second. **Cruise Mode Selected** appears on the driver information interface for two seconds, and then the mode switches to Cruise.

To switch back to ACC with Low Speed Follow, press and hold the (a) (interval) button again for one second. **ACC Mode Selected** appears on the driver information interface for two seconds.

#### ■ When to use

Desired speed in a range above roughly 25 mph (40 km/h).

#### ▼To Switch ACC with Low Speed Follow to Cruise Control ■ To Switch ACC with Low Speed Follow to Cruis

Always be aware which mode you are in. When you are driving in Cruise mode, the system will not assist you to maintain a following-interval from a vehicle ahead of you.

You can switch the displayed set speed measurements on the driver information interface between mph and km/h.

**Dunits** P. 138

### ■ To Set the Vehicle Speed

Take your foot off the pedal and press the **–/SET** button when you reach the desired speed.

The moment you release the **-/SET** button, the set speed is fixed, and cruise control begins. The  $\overline{ m}$  indicator (green) comes on.

When you use cruise control, Straight Driving Assist (a feature of the Electric Power Steering system) is activated.

By enabling the steering system to automatically compensate for natural steering pull, Straight Driving Assist makes it easier for you to keep your vehicle in a straight line.

## ■ To Adjust the Vehicle Speed

Each time you press the **RES/+** or **-/SET** button, the vehicle speed is increased or decreased by about 1 mph (1 km/h).

If you keep the **RES/+** or **-/SET** button pressed, the vehicle speed increases or decreases until you release it. This speed is then set.

### ■ To Cancel

To cancel cruise control, do any of the following:

- Press the CANCEL button.
  - ► The indicator (green) on the driver information interface change to the indicator (white.)
- Press the 🔀 button.
  - indicator (green) goes off.
- Depress the brake pedal.
  - ► The indicator (green) on the driver information interface change to the indicator (white.)

#### ∑To Cancel

Resuming the prior set speed:

After cruise control has been canceled, you can still resume the prior set speed by pressing the **RES/+** button while driving at a speed of at least 25 mph (40 km/h) or more.

You cannot set or resume in the following situations:

- When vehicle speed is less than 25 mph (40 km/h)
- When the R button is turned off.

At vehicle speeds of 22 mph (35 km/h) or less, cruise control canceled automatically.