SETTINGS FOR YOUR VEHICLE

Change different settings for many features in your vehicle. See your Owner's Manual for detailed information on settings and options.

Adjusting Vehicle Settings

Press SETTINGS to select the settings menu. Use the interface dial to make and enter selections.

Choose from the available options:

Navi Settings
Change various settings for navigation system routing.

Camera Settings
Change camera modes.

Vehicle Settings*
TPMS calibration, meter setup, door setup, and more.

*The shift lever must be in Park (P) to access this menu.

System Settings
Adjust the display, system language, and more.

Phone Settings
Pair a phone, change call and text/e-mail options, and more.

Info Settings
Import wallpaper and select clock type.

Audio Settings
Change sound options and various settings for audio modes.

DRIVING POSITION MEMORY SYSTEM (DPMS)

Store driver's seat positions into memory for each corresponding keyless remote transmitter (1 or 2).

Programming the DPMS

1. Turn on the vehicle. Make sure the shift lever is in Park (P).

2. Adjust the seat to your preferred position.

3. Press SET. You will hear a beep.

4. Press the memory button corresponding to the remote (1 or 2) you are using within 5 seconds. You will hear two beeps.

Note: Once set, stored positions can be recalled by pressing one of the memory buttons (1 or 2) on the door.

SYSTEM SETTINGS

You can customize the overall display and sounds on the audio/information screen.

Customization Flow

Models with navigation system
■ Customization flow

Press the SETTINGS button.

Settings menu   12:34
Navi Settings
Camera Settings   Phone Settings
Vehicle Settings   Info Settings
System Settings   Audio Settings

= ROTATE the Interface dial
= PRESS the Enter button

System Settings → Default

- Display
  - Brightness
  - Contrast
  - Black Level
- Sound/Beep
  - Volume
  - Interface Dial Feedback
  - Message Auto Reading
  - Verbal Reminder
- Bluetooth
  - Bluetooth Status
  - Bluetooth Device List
  - Edit Pairing Code
- Voice Recog.
  - Volume
  - Voice Prompt
  - Song by Voice
  - Song by Phonetic Modification
  - Phonebook Phonetic Modification
- Clock
  - Clock/Wallpaper Type → Clock / Wallpaper
  - Clock Adjustment
  - Clock Format
  - Auto Time Zone *
  - Auto Daylight *
  - Clock Reset
- Others
  - Units
  - Language
  - Voice Command Tips
  - Background Color
  - Header Clock Display
  - System Device Information
  - Factory Data Reset

* Not available on all models

VEHICLE SETTINGS

You can customize your vehicle's settings using the audio/information screen.

Customization Flow

Models with navigation system
☒ Customization flow

Press the SETTINGS button.

Settings menu   12:34
Navi Settings
Camera Settings   Phone Settings
Vehicle Settings   Info Settings
System Settings   Audio Settings

= ROTATE the Interface dial
= PRESS the Enter button

Vehicle Settings → Default

- TPMS Calibration
- Driver Assist System Setup
  - Forward Collision Warning Distance
  - ACC Pre-Running Car Detect Beep *＊1
  - ACC Display Speed Unit *
- Meter Setup
  - Language Selection *
  - Adjust Outside Temp. Display
  - Trip A Reset Timing
  - Trip B Reset Timing
  - Fuel Efficiency Backlight
  - Keyless Start Guidance Screens
- Driving Position Setup → Memory Position Link
- Keyless Access Setup
  - Door Unlock Mode
  - Keyless Access Light Flash
  - Keyless Access Beep
  - Interior Light Dimming Time
- Lighting Setup
  - Headlight Auto Off Timer
  - Auto Light Sensitivity
- Door Setup
  - Auto Door Lock
  - Auto Door Unlock
  - Key And Remote Unlock Mode
  - Keyless Lock Answer Back
  - Security Relock Timer
- Maintenance Info → Maintenance Reset

* Not available on all models
*1: Beeps when ACC detects a forward vehicle

CAMERA SETTINGS

You can customize the camera displays on the audio/information screen.

Customization Flow

Models with navigation system
■ Customization flow

Press the SETTINGS button.

Settings menu   12:34
Navi Settings
Camera Settings   Phone Settings
Vehicle Settings   Info Settings
System Settings   Audio Settings

= ROTATE the Interface dial
= PRESS the Enter button

Camera Settings

- LaneWatch → Default
  - Show with Turn Signal
  - Reference Lines
  - Next Maneuver Pop Up
  - Display
    - Brightness
    - Contrast
    - Black Level
    - Color
    - Tint
- Rear Camera → Default
  - Fixed Guidelines
 - Dynamic Guidelines

AUDIO SETTINGS

You can customize the audio settings on the audio/information screen.

Customization Flow

Models with navigation system
■ Customization flow

Press the SETTINGS button.

Settings menu   12:34
Navi Settings
Camera Settings   Phone Settings
Vehicle Settings   Info Settings
System Settings   Audio Settings

= ROTATE the Interface dial
= PRESS the Enter button

Audio Settings → Default

- Sound
- Source Select Setup
- HD Radio Mode
- Cover Art
- Connect Bluetooth Audio Device
- Bluetooth Device List
- Recording from CD
- Recording Quality
- HDD Info
- Gracenote Album DB Info Update
- Update Gracenote Album Info
- Delete All HDD Data
- USB/Bluetooth Connection Priority *

* Not available on all models
List shown contains all possible options. Specific menu choices will change depending on audio system mode.

PHONE SETTINGS

You can customize the phone settings on the audio/information screen.

Customization Flow

Models with navigation system
■ Customization flow

Press the SETTINGS button.

Settings menu   12:34
Navi Settings
Camera Settings   Phone Settings
Vehicle Settings   Info Settings
System Settings   Audio Settings

= ROTATE the Interface dial
= PRESS the Enter button

Phone Settings → Default

- Phone → Default
  - Connect Phone
    - Add Bluetooth Device
    - Disconnect
  - Bluetooth Device List
    - Edit Bluetooth Device
    - Add Bluetooth Device
  - Edit Speed Dial
  - Auto Transfer
  - Auto Answer
  - Ring Tone
  - Automatic Phone Sync
  - Use Contact Photo
- Text/Email → Default
  - Enable Text/Email
  - Select Account
  - New Text/Email Alert

NAVI/INFO SETTINGS

You can customize navigation and information settings on the audio/information screen.

Customization Flow

Models with navigation system
■ Customization flow

Press the SETTINGS button.

Settings menu   12:34
Navi Settings
Camera Settings   Phone Settings
Vehicle Settings   Info Settings
System Settings   Audio Settings

= ROTATE the Interface dial
= PRESS the Enter button

- Navi Settings → See Navigation System Manual.
- Info Settings → Default
  - Clock
    - Clock/Wallpaper Type
    - Clock Adjustment
    - Clock Format
    - Auto Time Zone *
    - Auto Daylight *
    - Clock Reset
  - Other
    - INFO Screen Preference

* Not available on all models