ULTRAWIDE REAR ENTERTAINMENT SYSTEM (RES) (ELITE only)

With the rear entertainment system and headphones, rear passengers can enjoy a different entertainment source than the front seat occupants.

RES Front Panel Controls



Rear Entertainment System

Pivot the earpieces to turn on or off. Wireless headphones only work in the rear seats.

Wired headphones may also be used.

Press OPEN to release the overhead screen.

Extend the screen until it locks into place.



Operating the RES from the Front

1. **Press** the REAR POWER button. Rear passengers will hear audio through the headphones.

2. **Press** the REAR SOURCE button. **Select** an entertainment source for the rear passengers.

3. **Press** the REAR SOURCE button again to return to the front audio controls.

Operating the RES from the Rear

1. **Press** the REAR POWER button from the front audio panel. **Press** the OPEN button and open the screen.

2. **Press** the SOURCE button to select an entertainment source.

3. **Press** the (▲) (▼) (◀) (▶) buttons to navigate the menu options. **Press** the ENTER button to select an option.

4. The rear control panel can be detached and used as a remote control. **Press** the release button to remove it.

Operating the Dual Screen Mode

Play two different entertainment sources side by side on the ultrawide rear screen.

One screen can play an entertainment source from the front audio system (FM, HDD, DVD, etc.). The other screen can play an entertainment source from rear AUX or HDMI input (external DVD player, video game console, etc.).

1. **Press** the DUAL button.



2. **Follow** the on-screen prompts to select which side the media source plays on.

Changing the Sound Source

While in dual screen mode, you can switch the sound source of the wireless headphones between the left and right screens.

Slide the tab to "L" for the left side or "R" for the right side.