HOMELINK® (if equipped)

The HomeLink Universal Transceiver can be programmed to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

Training a Button



1 Position the remote transmitter you wish to link 1–3 inches from the HomeLink button you want to program.

2 **Press and hold** the desired HomeLink button and the button on the remote transmitter.

Does the HomeLink indicator (LED) blink at a faster rate after about 10 seconds?

NO

a **Press and hold** the button on the remote and the HomeLink button at the same time. Then, while continuing to hold the HomeLink button, **press and release** the button on the remote every 2 seconds.

Does the LED blink at a faster rate within 20 seconds?

NO → repeat **a**

YES

YES → **3** **Press and hold** the programmed HomeLink button for about a second.

Does the device (garage door opener) work?

YES → **Training complete**

NO

4 **Press and hold** the HomeLink button again.

HomeLink indicator flashes for 2 seconds, then remains on.

a The remote has a rolling code. **Press** the “learn” button on the remote-controlled device (e.g., garage door opener).

b Within 30 seconds, **press and hold** the programmed HomeLink button for 2 seconds.

5 **Press** the programmed HomeLink button again; the remote-controlled device should operate.

HomeLink LED remains on.

If you have any problems programming HomeLink, see the owner’s manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit *www.homelink.com*.