BASIC AUDIO OPERATION

Operate basic controls of your audio system using several convenient methods.

Steering Wheel Controls

MODE button: Change audio source.

VOL (▲) button: Increase volume.

VOL (▼) button: Decrease volume.

CH (+) button: Go to next station or track.

CH (-) button: Go to previous station or track.

Touchscreen Controls

Audio Source: Select audio sources by their icons.

Preset: Select preset stations.

Shortcuts: Store AM, FM, or XM stations.

Skip/Seek: Change stations, albums, tracks, etc.

More: Select menu options, play modes, and sound settings.

USB Connection

Connect an iPhone or iPod dock connector or a USB flash drive to the USB port below the system.

iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Playing Audio Files

Select the iPod or USB icon from Audio Source.

1. Connect the iPod dock connector or USB flash drive to the USB port.
2. Select Audio Source and select the iPod or USB icon.
3. Use the touchscreen or steering wheel controls to change tracks.

Note: Connect your device only when your vehicle is stopped.

iPod is a trademark of Apple, Inc. iPod not included.

Searching for Music

Use the interface dial to make and enter selections.

1. Press FRONT AUDIO.
2. Press MENU.
3. Select Music Search.
4. Select a category or folder.
5. Select a track and press ENTER to begin playing.

HARD DISC DRIVE (HDD) AUDIO

Record CDs onto your vehicle's hard disc drive. Songs are automatically recorded once a CD is inserted into the disc slot.

Playing HDD Audio

Select the HDD icon from Audio Source.

1. Select Audio Source and select the HDD icon. The last recorded album begins playing.
2. Use the touchscreen or steering wheel controls to change tracks.

Searching for Music

Use the interface dial to make and enter selections.

1. Press FRONT AUDIO.
2. Press MENU.
3. Select Music Search.
4. Select one of the categories.
5. Select a track and press ENTER to begin playing.

SONG BY VOICE™ (SBV)

Play songs from your iPod and HDD from most screens by using simple voice commands.

Using the "Play" Command

Press and release the Talk button before you say a command.

1. Say "*Music search*."
2. Say "*Play*" and a search option. For example, "*Play artist XYZ*" or "*Play song XYZ*."
3. The system plays the first song by the artist or the specified song and returns to your original screen.

Using the "List" Command

Press and release the Talk button before you say a command.

1. Say "*Music search*."
2. Say "*List*" and a search option. For example, "*List artist XYZ*" or "*List album XYZ*."
3. A list of tracks by the artist or album is displayed. Say the number of your selection. For example, "*One*."
4. The system plays the selected song and returns to your original screen.

BLUETOOTH® AUDIO

Stream audio wirelessly from your phone through your vehicle's audio system. Visit *handsfreelink.honda.com* to check if this feature is compatible with your phone.

Playing *Bluetooth* Audio

Select the Bluetooth icon from Audio Source.

1. Make sure your phone is on and paired to *Bluetooth*® HandsFreeLink® and the screen is on and unlocked.
2. Select Audio Source and select the Bluetooth icon.
3. From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system. Make sure the volume on your phone is properly adjusted.
4. Use the touchscreen or steering wheel controls to change tracks.

Notes:

- You may need to enable additional settings on your phone for playback.
- The play/pause function and remote audio controls are not supported on all phones.
- Connect your phone only when your vehicle is stopped.