

Rear Seats

Rear seats can be folded up or down separately to allow for additional storage space.

Folding Down Rear Seats

1. Store the center seat belt. Insert the latch plate into the slot on the side of the anchor buckle. Retract the seat belt into the holder on the ceiling.
2. Lower the head restraint to its lowest position.
3. Pull the release lever and fold down the seat-back.





NOTICE

Make sure all items in the cargo area or items extending to the rear seats are properly secured. Loose items can fly forward if you have to brake hard.

To return the seat to the original position, pull up the seat-back to the upright position.


Folding Up Rear Seats

1. Make sure the seat belt buckles are in their loops on the seat.
2. Pull up the rear seat cushion.
3. Fold the seat leg down while pushing the seat cushion firmly against the seat-back to lock it.



To return the seat to its original position, hold the seat cushion in the upright position and pull up the seat leg fully. Slowly put down the seat cushion and set the seat leg in the floor guide. A latch comes out when the leg is set properly.

Make sure the seat is firmly secured by rocking it forward and back.



■ **Adjusting the Rear Seats**

Pull the release lever on the left or right side to change the angle of the seat-back.

