


Models with Display Audio

HondaLink® Assist

If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle automatically attempts to connect to an operator. Your phone must be paired to the system and have good cellular connection. Visit www.hondalink.com (U.S.) for more information.

1. Make sure your phone is on and paired to *Bluetooth HandsFreeLink*.
2. Select *Call Now*, or the system automatically connects after 10 seconds. The vehicle information and its position may be sent to the operator.*
3. Select *Talk Now* to immediately talk to the operator.
4. When the call is complete, select *Hang Up* or press the *Hang-Up/Back* button on the steering wheel.



Wi-Fi Connection

You can connect the audio system to the internet using Wi-Fi and use online services through the touchscreen. If your compatible phone has hotspot capabilities, the system can be tethered to the phone. Follow the steps below to set up Wi-Fi when the vehicle is stopped. Standard data rates apply with your phone service provider.

1. From the Home screen, select *Settings*.
2. Select *Bluetooth/Wi-Fi*. Select the *Wi-Fi* tab.
3. Select *Wi-Fi On/Off Status*, select *Next*, then select *On*.
4. Select *Yes*.
5. Select *Wi-Fi Device List*. Make sure your phone's Wi-Fi setting is in access point (tethering) mode.
6. Select the phone you want to connect to the system. If the phone you want to connect does not appear, select *Scan*.
7. Select *Add*.
8. Enter a password for your phone, if necessary. Select *Done*. The Wi-Fi symbol is displayed on the list when connection is successful.



**Depending on your phone and cellular signal capability, your vehicle's location may not be sent to the operator.*