

■ Paddle Shifters*

Use the paddle shifters to change gears without removing your hands from the steering wheel.

(-) paddle shifter:
Pull to shift down
to a lower gear.





(+) paddle shifter:
Pull to shift up to
a higher gear.



Recommended shift points

Shift up	Normal acceleration
1 to 2	15 mph (24 km/h)
2 to 3	25 mph (40 km/h)
3 to 4	40 mph (64 km/h)
4 to 5	47 mph (76 km/h)
5 to 6	52 mph (84 km/h)
6 to 7	57 mph (92 km/h)



M indicator/gear
position indicator

When driving in ECON or NORMAL mode: The vehicle goes into manual shift mode temporarily, and the gear number appears in the shift indicator. When you start traveling at a constant speed or accelerate, manual shift mode automatically switches off, and the gear number goes off.

When driving in SPORT mode: The vehicle goes into manual shift mode, and the M indicator and gear number appear in the shift indicator. If the vehicle speed increases and the engine speed approaches the tachometer's red zone, the transmission automatically shifts up. As the vehicle speed slows down, the transmission automatically shifts down accordingly. When the vehicle comes to a stop, it automatically shifts down into 1st gear.

You can cancel manual shift mode by pressing any of the three driving mode buttons, or by pulling the (+ paddle shifter for a few seconds.

L mode operation: Use L mode when you want to increase engine braking to maximum when in manual shift mode, when going up or down hills, or when the IMA battery is low. Pull and hold both paddle shifters (+) and (-) at the same time. The L indicator is displayed in the shift indicator. To cancel this mode, pull and hold both paddle shifters again, or press any of the three driving mode buttons. The L indicator goes off.

*if equipped