

## Honda Sensing™\*

Honda Sensing is a driver support system which employs the use of two distinctly different kinds of sensors, a radar sensor located at the lower part of the front bumper and a front sensor camera mounted to the interior side of the windshield, behind the rear view mirror. These are the components of Honda Sensing:

**Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)\*:** Helps maintain a constant vehicle speed and a set following interval behind a vehicle detected ahead of yours and, if the detected vehicle comes to a stop, can decelerate and stop your vehicle.

**Lane Keeping Assist System (LKAS):** Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

**Road Departure Mitigation (RDM) System:** Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

**Collision Mitigation Braking System (CMBS):** Can assist you when there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of yours.


*\*if equipped*

## Lane Keeping Assist System (LKAS)\*

A camera mounted between the windshield and the rearview mirror determines if your vehicle begins to move away from the center of a detected lane while driving between 45–90 mph (72–145 km/h).




If you cross a detected lane line without using your turn signal, a message appears on the DII and a beep sounds.

Light steering torque is applied to help keep your vehicle within the lane.



### ■ Turning LKAS On or Off

1. Press the MAIN button. LKAS appears in the driver information interface (DII).
2. Press the LKAS button. Lane outlines appear in the DII. Dotted lane lines turn solid when the system starts operating.
3. Press the MAIN or LKAS button to turn the system off.



### Important Safety Reminder

LKAS is for your convenience only. It is not a substitute for your vehicle control. The system does not work if you take your hands off the steering wheel or fail to steer the vehicle.

Do not place an object on the top of the instrument panel. It may reflect onto the windshield and prevent the system from detecting lane lines properly.