

Honda Sensing® is a driver support system which employs the use of two distinctly different kinds of sensors: a radar sensor located inside the front grille and a front sensor camera mounted to the interior side of the windshield, behind the rearview mirror.

Honda Sensing® has following functions.


■ **The functions which do not require switch operations to activate**

- Collision Mitigation Braking System™ (CMBST™) ⓘ P. 589
- Road Departure Mitigation (RDM) System ⓘ P. 625
- Traffic Sign Recognition System ⓘ P. 630

■ **The functions which require switch operations to activate**

- Adaptive Cruise Control (ACC) with Low Speed Follow ⓘ P. 600
- Lane Keeping Assist System (LKAS) ⓘ P. 616

■ Operation Switches for the ACC with Low Speed Follow/ LKAS



■ Button

Press to activate standby mode for ACC with Low Speed Follow. Or press to cancel the system.

■ LKAS Button

Press to activate standby mode for LKAS. Or press to cancel this system.

■ RES/+ and -/SET Buttons

Press **RES/+** button to resume the ACC with Low Speed Follow or increase the vehicle speed.

Press **-/SET** button to set the ACC with Low Speed Follow or decrease the vehicle speed.

■ Interval Button


Press to change the ACC with Low Speed Follow following-interval.

■ CANCEL Button

Press to cancel ACC with Low Speed Follow.

Continued

■ Driver Information Interface Content



You can see the current state of ACC with Low Speed Follow, and LKAS.

- ①** Indicates that ACC with Low Speed Follow is ready to be activated.
- White: The system is in standby.
 - Green: The system is on.
 - Amber: There is a problem with the system.

- ②** Indicates that LKAS is ready to be activated.
- White: The system is in standby.
 - Green: The system is on.
 - Amber: There is a problem with the system.

- ③** Indicates that LKAS is activated and whether or not traffic lane lines are detected.
- Solid line: The system is on.
 - Contour line: The system is in standby.

- ④** Indicates whether or not ACC with Low Speed Follow detects the vehicle ahead.

- ⑤** Shows vehicle set speed in ACC with Low Speed Follow.

- ⑥** Shows set vehicle interval in ACC with Low Speed Follow.